
Print Exit

6AR-FSE ENGINE CONTROL SFI SYSTEM DETAILS CRANKSHAFT POSITION SENSOR

CONSTRUCTION

- **a.** A Magnetic Resistance Element (MRE) type crankshaft position sensor is used to detect the engine speed and crankshaft angle.
- **b.** The crank angle sensor plate (timing rotor) of the crankshaft consists of 34 teeth with 2 teeth missing. The crankshaft position sensor outputs a crankshaft rotation signal every 10°, and the change of the signal due to the missing teeth is used to determine top-dead-center.



© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.

1 of 1 3/30/2021, 1:22 PM